

FREIGHTLINER

**Prior to 1984 COE and Conv.
92" Long**



CA0010



CA1110

**1986 and Newer Conv. Set Back
Axle W/17" Break-Back**



CD2010

**1986 and Newer COE W/2" Break-Back
FLC 112 Conv. (Steel Cab)**



CE1110

**FLD 120 W/6" Break-Back
(Specify Length 92" or 86-3/4")**



CH2010



CJ2010

**Prior to 204 Columbia Set Back
Axle Chrome Replacement,
Brackets Included)**



CN2011

FL 50, 60, 70, 80 (Midrange)



CK2200

**1984 - 1999 COE and Conv. 92" Long
Freightliner Classic**



CB2010



CB0010

**FLD 112 Severe Duty Set Back Axle
W/17" Break-Back**



CP2011

**1986 and Newer Conv. Set Back
Axle W/17" Break-Back**



CD2010

**Combination of FLD 112 & FLD 120
Bolt Patterns W/6" Break-Back (Specify
Length 92" or 86-3/4")**



CM2011

**Conventional Set Back Axle (Chrome
Replacement) 2005 Century Class
(Brackets Included) 2000 - 2004
Century Class (Brackets Included)**



CL2210

FL112 (Midrange)



CR2200

2000 - 2002 Classic 92" Long



CQ2210

2003 Classic 92" Long



CS2110

1989 and Newer COE W/7" Break-Back



CF2111

**FLD 112 W/6" Break-Back
(Specify Length 92" or 86-3/4")**



CG2011

**1989 and Newer Conventional Set Back
Axle (Chrome Replacement) FLD 112,
FLD 120) (Factory Rebar Required)**



CI2111

**Conventional Set Back Axle (Chrome
Replacement) 2005 Century Class (Brackets
Included) 2005 Century Class (Brackets
Included) 2004 and Newer Columbia**



CW2011

**2003 and Newer Business Class M2
(Midrange)**



CT0001