

PETERBILT

1967 - 1986 Conv. 359, 196 - 1980 COE 352




HA1010



HA0010

1987 and Newer Conv. 375 W/2" Break-Back



HD2011

1987 and Newer Conv. 378, 379




HC2010




HC0010

1987 - 1996 Conv. 377, Prior to 1991 377AE Set Back Axle (Brackets Included)




HH2010

Prior to 1991 Conv. 377 Set Forward



HI2010

1991 and Newer Conv. 377AE Set Forward Axle



HJ2010

1999 - 2001 387 Set Back Axle (Brackets Included)



HR2210

2002 and Newer 387 Set Back Axle (Brackets Included)



HS2210

WESTERN STAR

COE Western Star W/2" Break Back



IB1010

1989 and Newer Conv. Western Star, 4964 Constellation, Heritage



IC2010

1985 - 1988 Western Star



IF2010

VOLVO

VNL510, VNL660, VNL770, Set Back Axle (Brackets Included)



LB4010

1998 and Newer VNM42T, VNM64T Set Back Axle (Brackets Included)



LD0010

VNL42T, VNL64T Set Back Axle (Brackets Included)



LE2011

2004 and Newer VED12-435 Set Back Axle (Brackets Included)



LG0010

2004 and Newer Model 780 Set Back Axle (Brackets Included)



LH2011